



VE712BN

Description: ENDURAFLEX Black, soft natural and nitrile rubber lining for abrasion and moderate oil resistance. Exhaust Steam or Pressure Cure.

Durometer of Face Material: Shore A Scale

Pressure Cure: 65 to 75

Atmospheric Cure: 65 to 75

Available Gauges: 1/8", 3/16", 1/4"; 4mm, 5mm, & 6mm.

Adhesive System:

Adhesives: ENDURABOND 1*2*3 SYSTEM

1st coat on metal:	Primer #1
2nd coat on metal:	Intermediate #2
3rd coat on metal:	Tack #3
On the rubber:	Tack #3

Skive: Open

Cure Methods and Times:

Autoclave: 1/8" to 1/4" -1 hour @ 275°F (135°C) 3/8" to 1/2" - 2 hours @ 275°
Internal Pressure: 8 hours @ 260°F (127°C)
Atmospheric: 2 Step process Step 1 - 6 hours from Ambient to 160°F (71°C) Step 2 - 24 hours @ 180°F (82°C) or 20 hours @ 200°F (94°C) Atmospheric curing not recommended for vacuum service.

Note: Cure times may require adjustment to compensate for heavy metal thickness, low exterior temperatures or other unusual factors. See Section 14 - Curing Instructions.

Repairs: Repair with original lining. See Section 16 - Repair Procedures.

Storage Life:

From 32°F (0°C) to 50°F (10°C)	180 days
From 51°F (13°C) to 65°F (19°C)	90 days
From 66°F (21°C) to 75°F (23°C)	60 days
From 75°F (23°C) to 85°F (30°C)	30 days
Do not exceed 90°F (32°C) prior to use.	Cold storage

Typical Physical Properties

Tensile Strength - PSI	ASTM D412	2900
% Elongation at break	ASTM D412	400
Durometer	ASTM D2240	68A
Specific Gravity	ASTM D927	1.17
Adhesion to Metal	ASTM D429	30 Lbs.

Application methods shall conform to BLAIR Rubber Company instructions contained in the Engineering & Applicator manual. Deviations from the specifications must be approved by BLAIR Rubber Company.

Notes: For the best appearance of the completed rubber lining, always apply plastic side down against the substrate.

Caution: Soft natural rubber is susceptible to deterioration by sunlight and oxygen called weather checking. **Do not** expose rubber lining to sunlight, ozone or oxygen.

Applicator notes:

1. A heated table that warms rubber to 120°F is best for application.
2. Lining may shrink after unrolling from roll. **Preshrink rubber before applying.**
3. The temperature of the substrate must be greater than 60° F (15° C) prior to applying primer and rubber. Temperatures should not exceed 120° F (48° C).



Section 2: Lining Specification

Date: January 7, 2005

Revision No. 4